Instructions





Blown SW4 Samuel Wilkinson 2018

Congratulations with your new Blown lamp, designed in 2018 by Samuel Wilkinson. We hope you will enjoy using this product and follow these instructions to ensure correct installation. If you have any questions or comments, please do not hesitate to contact us by mail on:

info@andtradition.com

Blown SW4 Samuel Wilkinson 2018





Please read these instructions carefully and retain them for future reference to ensure that the product is used correctly. For your own safety, please study each step of this instruction manual first. & Tradition is not responsible for any faults or damages caused by not following these instructions correctly. Do not modify this product in any way.

Contents

- A Shade
- **B** Canopy with metal ceiling bracket
- C Connection box

Tools needed


- Small flat-head screwdriver for wiring
- Bulb type E14

Safety precautions

- Dispose of plastic bag from packaging and do not allow children to play with it.
- Keep product well out of children's reach.
- The product is only intended for interior use.
- Do not attempt installation of product if you are not competent to do so yourself.
- Consult a professionally qualified electrician if in any doubt.
- Disconnect the electricity supply at the fuse box, before commencing work.

Cleaning instructions

- Wipe surface of lamp shade with a soft, damp sponge or cloth, and wipe immediately after with a dry cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, terpentine, household glass cleaner or cellulose thinners.



Step 1

Ensure power supply is turned off and remove any existing lamp fitting.


Locate the supply cable and ensure it is ready to be fitted to the connector block.

Mount the metal bracket (B) securely in the ceiling with screws and wall plugs, appropriate for the ceiling of installation.




Step 2

Drill a whole into the side of the canopy and pull electric cord through it




Step 3

To determine the right suspension height for the lamp, pass the electrical cord through the strain relief of the metal bracket. (B) When you have the desired suspension height of the lamp, tighten the plastic screw of the strain relief.




Step 4

Use the terminal box inside the connection box (C) to assemble the wires from the pendant with the wires from the power supply. Close the connection box and place it inside the canopy.








Step 5

Install the plastic canopy (B) onto the metal plate.



Step 6

Install the light bulb.

&Tradition®